



ELITE ARCHERY CAM ADJUSTMENT BASICS

ADJUSTMENT	ADJUSTMENT RESULTS					
	CAM ROTATION	DRAW LENGTH	DRAW WEIGHT	VALLEY / LETOFF	ATA	BRACE HEIGHT
TWISTING CABLES	ADVANCE	INCREASE	INCREASE	SLIGHTLY INCREASE	DECREASE	SLIGHTLY INCREASE
UNTWISTING CABLES	RETARD	DECREASE	DECREASE	SLIGHTLY DECREASE	INCREASE	SLIGHTLY DECREASE
TWISTING STRING	RETARD	DECREASE	DECREASE	SLIGHTLY DECREASE	SLIGHTLY DECREASE	SLIGHTLY INCREASE
UNTWISTING STRING	ADVANCE	INCREASE	INCREASE	SLIGHTLY INCREASE	SLIGHTLY INCREASE	SLIGHTLY DECREASE
MOVE IN DRAW STOPS *	SLIGHTLY RETARD	SLIGHTLY DECREASE	_____	SHORTENS VALLEY, DECREASE LETOFF	_____	_____
MOVE OUT DRAW STOPS *	SLIGHTLY ADVANCE	SLIGHTLY INCREASE	_____	INCREASES VALLEY, INCREASE LETOFF	_____	_____

* Adjustments should be made in very small amounts. When making adjustments it is recommended that you stay within the designated range suggested by the manufacturer. Failure to do so may allow cams to over-rotate, resulting in the bow "locking up" at full draw, which could cause serious injury!

